

		VUELTAS				
VIENTO	LIBRAS	SCALE	ALTOS	BAJOS	CAIDA	
0-4	350	30,5	-2 1/2	-2	29" 1/2	
5-10	400	32,5	-1	-1	29" 1/2	
11-13	450	34	0	0	29"	
14-16	500	35,5	1	1	28" 1/2	
17-19	550	36,8	2	2	28"	
20-25	600	37,8	3	4	27" 1/2	
26 +	650	38,5	4	5	27"	
26 +	700	39	4 1/2	5	27"	
26 +	750	39,5	5	5	27"	
26 +	800	40	5 1/2	5	27"	

*** Ajustar = Sentido Antihorario***